

Bosch Dishwasher

Everyday operation, care, and first-step troubleshooting.

KITCHEN · 2026 EDITION

Bosch Dishwasher: the useful basics

This compact guide covers general operation and care for the equipment family shown. Controls and procedures vary by model, so locate the complete model number and consult the manufacturer manual before service.

01

Cycle overview

Use Auto for mixed everyday loads, Heavy for baked-on soil, and a short cycle for lightly soiled items. Options can change run time.

02

Loading tips

Face dirty surfaces toward the spray arms, keep tall items clear of the detergent cup, and verify both spray arms rotate freely.

03

Cleaning and care

Rinse the filter under warm water regularly. Wipe the door seal and inspect spray-arm openings for mineral buildup.

SAFETY FIRST

Shut off the house circuit breaker before opening the control panel.

FEATURED REPLACEMENT PART

Control Panel Button · Part 00165246

The featured part comes from the current retailer catalog. Confirm compatibility using the complete equipment model number before purchase. Price and availability can change.

Prototype guide - not a manufacturer-issued owner or service manual. Complex electrical, gas, refrigerant, and structural repairs should be completed by a qualified professional.