

GE Dishwasher

Everyday operation, care, and first-step troubleshooting.

KITCHEN · 2026 EDITION

GE Dishwasher: the useful basics

This compact guide covers general operation and care for the equipment family shown. Controls and procedures vary by model, so locate the complete model number and consult the manufacturer manual before service.

01

Cycle selection

Use a normal cycle for everyday loads and a heavier cycle for baked-on soil. Options can add heat, drying time, or extra rinses.

02

Loading patterns

Face soiled surfaces toward the spray arms and keep tall items clear of the detergent cup and upper manifold.

03

Filter and spray-arm care

Clean the filter regularly and confirm every spray arm turns freely with its openings clear.

SAFETY FIRST

Disconnect electrical power and close the water supply before service.

FEATURED REPLACEMENT PART

Upper Spray Arm Manifold Ring Nut and Gasket · Part WD01X10242

The featured part comes from the current retailer catalog. Confirm compatibility using the complete equipment model number before purchase. Price and availability can change.

Prototype guide - not a manufacturer-issued owner or service manual. Complex electrical, gas, refrigerant, and structural repairs should be completed by a qualified professional.