

Samsung Washer

Everyday operation, care, and first-step troubleshooting.

LAUNDRY · 2026 EDITION

Samsung Washer: the useful basics

This compact guide covers general operation and care for the equipment family shown. Controls and procedures vary by model, so locate the complete model number and consult the manufacturer manual before service.

01

Cycle overview

Match cycle, water temperature, and spin speed to the fabric label. Leave enough space for the load to move freely.

02

Drain-filter care

Inspect and clean the accessible pump filter on the schedule in the model instructions, keeping towels ready for residual water.

03

Balance troubleshooting

Redistribute a single heavy item, level the cabinet, and confirm all shipping hardware was removed if vibration persists.

SAFETY FIRST

Unplug the washer and shut off both water supplies before service.

FEATURED REPLACEMENT PART

Drain Pump Cover · Part DC61-03187A

The featured part comes from the current retailer catalog. Confirm compatibility using the complete equipment model number before purchase. Price and availability can change.

Prototype guide - not a manufacturer-issued owner or service manual. Complex electrical, gas, refrigerant, and structural repairs should be completed by a qualified professional.